FIG. 1





FIG. 2



## FIG. 9A

Value						
NAR_ATTR Type	NAR_ATTR Code NAR_A	TTR Qualifier	NAR_ATTR Length			
0 1 2 3 4 5 6	8 9 0 1 2 3 4 5 6 7 8	9 0 1 2 3	4 5 6 7 8 9 0 1			
_		_				
204	·.`		206a			

## FIG. 9B

NAR_ATTR Type	NAR_ATTR Code UINT8	NAR_VALUE
0 1 2 3 4 5 6 7	8 9 0 1 2 3 4 5 6 7 8 9 0 1 2 3 4	5 6 7 8 9 0 1
204	$I \setminus \Re L$	,206b

## FIG. 10

210						
0 1 2 3 4 5 6 7	8 9 0 1 2 3 4 5	6 7 8 9	2 0 1 2 3	4 5 6 7 8 9 0 1		
NAR_ATTR Type	NAR_ATTR Code	NAR_ATT		NAR_ATTR Length		
			Туре	,		
0x10	0x00		TIME	3		
. Seconds						
Seconds						

FIG. 32

	ADMIN	SCHEDULE	EVENT& LOG	TOPOLOGY	DIRECTORY	EXTERN	AL • • •	79	O, PROV.MOD MUTE-
أرم	PROVIS	IONING SER	/ICES, 782	2					
	CONFIGURATION MANAGEMENT, 784								
	ELEMEN'	T MANAGEM	ENT , 786						
	Contivity		Routing / Switching		Multi- vendor	•••	NE 1	NE n	788, NETWORK MULTI- ELEMENTS DEVICE